

ST-EX2023

Installation Instructions / Instructions d'installation / Montageanweisung / Instrucciones de instalación / Istruzioni di installazione / 取扱説明書 / 安装说明书

English

Materials included in package

1. ST-EX2023 with attachment foot for EX201W x 1
2. Attachment foot for EX231W or EX231Wp x 1
3. Rubber feet x 2
4. Quick Start Guide x 1

Deutsch

Materials included in package

1. ST-EX2023 with attachment foot for EX201W x 1
2. Attachment foot for EX231W or EX231Wp x 1
3. Rubber feet x 2
4. Quick Start Guide x 1

Italiano

Materials included in package

1. ST-EX2023 with attachment foot for EX201W x 1
2. Attachment foot for EX231W or EX231Wp x 1
3. Rubber feet x 2
4. Quick Start Guide x 1

简体中文

Materials included in package

1. ST-EX2023 with attachment foot for EX201W x 1
2. Attachment foot for EX231W or EX231Wp x 1
3. Rubber feet x 2
4. Quick Start Guide x 1

Français

Materials included in package

1. ST-EX2023 with attachment foot for EX201W x 1
2. Attachment foot for EX231W or EX231Wp x 1
3. Rubber feet x 2
4. Quick Start Guide x 1

Español



Materials included in package

1. ST-EX2023 with attachment foot for EX201W x 1
2. Attachment foot for EX231W or EX231Wp x 1
3. Rubber feet x 2
4. Quick Start Guide x 1

日本語

Materials included in package

1. ST-EX2023 with attachment foot for EX201W x 1
2. Attachment foot for EX231W or EX231Wp x 1
3. Rubber feet x 2
4. Quick Start Guide x 1



Français

Précautions de sécurité (remarque sur les symboles utilisés ici)
Assurez-vous de lire attentivement les descriptions suivantes avant l'installation.

Avertissement

Les éléments marqués de ce symbole contiennent des instructions qui, si elles sont ignorées ou mal suivies, peuvent entraîner la mort ou des blessures.

Attention

Les éléments marqués de ce symbole contiennent des instructions qui, si elles sont ignorées ou mal suivies, peuvent entraîner des blessures ou endommager les biens.

Avertissement

- Lorsque vous installez votre moniteur MultiSync, assurez-vous de le faire correctement selon les instructions données ici. Si l'installation est incorrecte, le moniteur MultiSync risque de basculer et par conséquent de blesser quelqu'un.
- Assurez-vous de suivre les instructions d'assemblage dans l'ordre où elles sont données et de serrer fermement toutes les vis à l'emplacement prévu. Si vous ne suivez pas les instructions, le moniteur risque de basculer, de tomber, d'être endommagé ou d'entraîner d'autres accidents imprévus après l'installation du moniteur MultiSync.
- Ne modifiez jamais les composants fournis car cela pourrait entraîner le basculement du moniteur MultiSync et par conséquent blesser quelqu'un.
- N'utilisez jamais de pièces ou composants endommagés car cela pourrait entraîner le basculement du moniteur MultiSync et par conséquent blesser quelqu'un. Si vous trouvez des pièces ou composants endommagés, contactez le magasin dans lequel vous avez acheté le produit pour obtenir de l'aide.
- Lorsque vous déplacez le support et le moniteur MultiSync alors qu'ils sont fixés ensemble, ne les déplacez jamais en tenant uniquement le support car cela pourrait entraîner le basculement du moniteur MultiSync et par conséquent blesser quelqu'un.

Attention

- Lorsque vous fixez un moniteur MultiSync au support, assurez-vous de bien tenir en place le moniteur MultiSync. Si vous ne le faites pas, le moniteur pourrait basculer et par conséquent blesser quelqu'un.
- Lorsque vous fixez le moniteur MultiSync, mettez ce dernier ainsi que tout autre appareil raccordé hors tension et retirez le cordon d'alimentation de la prise murale avant de le faire.

Installing stand:
You use this stand for both size 20" (EX201W) and 23" (EX231W/EX231Wp) by change attachment foot.
CAUTION: Do not use this stand for EX201W with attachment foot for EX231W/EX231Wp. It may cause monitor fall down and make serious damage to the monitor.

For EX201W

Unité: mm

Poids: ??

132.1

For EX231W / EX231Wp

Poids: ??

141.4

For EX201W user: Proceed to step 3.

For EX231W or EX231Wp user: Change attachment foot following the below instruction.

- 1 Press Quick Release Button **A** and pull out the attachment foot.
- 2 Attach the attachment foot with "23 only".
- 3 1) Turn off the power to the monitor.
2) Paste two rubber feet **B** on the bottom of the monitor.
3) Place monitor face down on a non-abrasive surface.
NOTE: Handle with care when placing monitor face down to avoid damaging the front control keys.Put the upper hooks of the stand in the slot of the monitor then push stand into monitor in direction of the arrow as shown and confirm that the stand is locked. Open the stand with widely extended until feeling a "click" feeling.
To reattach the stand, please refer to monitor's user's manual.

Before using:
Use this stand with widely extended until feeling a "click" feeling.
CAUTION: Improper setting may cause the monitor fall down and make serious damage to the monitor.
Human Sensor position is below as normal stand. Please make sure there is no object in front of Human Sensor.
Be sure to observe the cautions described in the monitor's operating manual when handling the monitor.

English

Safety Precautions (A note on symbols used herein)
Be sure to read the following descriptions carefully before installing.

Warning

Items marked with this symbol indicate items containing instructions which, if ignored or improperly followed, might result in death or bodily injury.

Caution

Items marked with this symbol indicate items containing instructions which, if ignored or improperly followed, might result in bodily injury or damage to property.

Warning

- When installing your MultiSync monitor, be sure to have it installed correctly in accordance with the instructions given herein. Improper installation may cause the MultiSync monitor to tip over, and this in turn might result in bodily injury.
- Be sure to follow the assembly instructions in the order they are given and to firmly screw in all screws in their designated locations. Failure to follow instructions might cause the monitor to tip over, fall down, become damaged, or result in other unforeseen accidents after the MultiSync monitor has been installed.
- Never alter any of the provided components, as doing so might result in the MultiSync monitor tipping over, which might in turn result in bodily injury.
- Never use any damaged parts or components, as doing so might result in the MultiSync monitor tipping over, which might in turn result in bodily injury. If you do find any damaged parts or components, contact the retail store where the product was purchased for assistance.
- When moving the stand and MultiSync monitor while they are still attached together, never move the stand and monitor by holding the stand alone, as doing so might result in the MultiSync monitor tipping over, which might in turn result in bodily injury.

Caution

- When attaching a MultiSync monitor to the stand, be sure to hold the MultiSync monitor in place when doing so, as failing to hold the monitor in place might result in it tipping over, which might in turn result in bodily injury.
- When attaching the MultiSync monitor, turn off the power to the monitor and any connected devices and remove the power cord from the power socket before doing so.

Installing stand:
You use this stand for both size 20" (EX201W) and 23" (EX231W/EX231Wp) by change attachment foot.
CAUTION: Do not use this stand for EX201W with attachment foot for EX231W/EX231Wp. It may cause monitor fall down and make serious damage to the monitor.

For EX201W

Unit: mm

Weight: ??

132.1

For EX231W / EX231Wp

Weight: ??

141.4

For EX201W user: Proceed to step 3.

For EX231W or EX231Wp user: Change attachment foot following the below instruction.

- 1 Press Quick Release Button **A** and pull out the attachment foot.
- 2 Attach the attachment foot with "23 only".
- 3 1) Turn off the power to the monitor.
2) Paste two rubber feet **B** on the bottom of the monitor.
3) Place monitor face down on a non-abrasive surface.
NOTE: Handle with care when placing monitor face down to avoid damaging the front control keys.Put the upper hooks of the stand in the slot of the monitor then push stand into monitor in direction of the arrow as shown and confirm that the stand is locked. Open the stand with widely extended until feeling a "click" feeling.
To reattach the stand, please refer to monitor's user's manual.

Before using:
Use this stand with widely extended until feeling a "click" feeling.
CAUTION: Improper setting may cause the monitor fall down and make serious damage to the monitor.
Human Sensor position is below as normal stand. Please make sure there is no object in front of Human Sensor.
Be sure to observe the cautions described in the monitor's operating manual when handling the monitor.

Deutsch

Sicherheitshinweise (Eine Anmerkung zu den hier verwendeten Symbolen)
Lesen Sie vor der Montage die folgenden Beschreibungen sorgfältig durch.

Achtung

Die mit diesem Symbol gekennzeichneten Teile weisen auf Teile hin, die Anweisungen enthalten, die, wenn sie ignoriert oder falsch befolgt werden, zu Tod oder Körperverletzungen führen können.

Vorsicht

Die mit diesem Symbol gekennzeichneten Teile weisen auf Teile hin, die Anweisungen enthalten, die, wenn sie ignoriert oder falsch befolgt werden, zu Körperverletzungen oder Sachschäden führen können.

Achtung

- Stellen Sie bei der Montage Ihres MultiSync Monitors sicher, dass er in Übereinstimmung mit den hier angeführten Anweisungen montiert wird. Unsachgemäße Montage kann zum Umkippen des MultiSync Monitors und als Folge zu Körperverletzungen führen.
- Folgen Sie den Montagevorschriften in der vorgegebenen Reihenfolge und schrauben Sie alle Schrauben an den dafür vorgesehenen Stellen fest ein. Das Nichtbefolgen der Anweisungen kann Umkippen, Herunterfallen, Monitorschäden oder andere unvorhergesehene Unfälle nach der Montage des MultiSync Monitors verursachen.
- Verändern Sie nie die mitgelieferten Teile, da dies zum Umkippen des MultiSync Monitors und als Folge zu Körperverletzungen führen kann.
- Benutzen Sie nie beschädigte Bauelemente oder Teile, da dies zum Umkippen des MultiSync Monitors und als Folge zu Körperverletzungen führen kann. Wenn Sie beschädigte Bauelemente oder Teile entdecken, wenden Sie sich an den Händler, bei dem das Produkt erworben wurde, um Hilfe zu erhalten.
- Falls Sie den Ständer zusammen mit dem MultiSync Monitor bewegen, während diese noch miteinander verbunden sind, bewegen Sie den Ständer und den Monitor nie, indem Sie nur den Ständer alleine anfassen, da dies zum Umkippen des MultiSync Monitors und als Folge zu Körperverletzungen führen kann.

Vorsicht

- Vergewissern sie sich beim Anbringen des MultiSync Monitors an den Ständer, dass der MultiSync Monitor richtig platziert ist, da eine fehlerhafte Platzierung zu seinem Umkippen und als Folge zu Körperverletzungen führen kann.
- Schalten Sie beim Anbringen des MultiSync Monitors die Stromversorgung des Monitors und aller an ihn angeschlossenen Geräte ab und entfernen Sie vorher das Stromkabel von der Steckdose.

Installing stand:
You use this stand for both size 20" (EX201W) and 23" (EX231W/EX231Wp) by change attachment foot.
CAUTION: Do not use this stand for EX201W with attachment foot for EX231W/EX231Wp. It may cause monitor fall down and make serious damage to the monitor.

For EX201W

Einheit: mm

Gewicht: ??

132.1

For EX231W / EX231Wp

Gewicht: ??

141.4

For EX201W user: Proceed to step 3.

For EX231W or EX231Wp user: Change attachment foot following the below instruction.

- 1 Press Quick Release Button **A** and pull out the attachment foot.
- 2 Attach the attachment foot with "23 only".
- 3 1) Turn off the power to the monitor.
2) Paste two rubber feet **B** on the bottom of the monitor.
3) Place monitor face down on a non-abrasive surface.
NOTE: Handle with care when placing monitor face down to avoid damaging the front control keys.Put the upper hooks of the stand in the slot of the monitor then push stand into monitor in direction of the arrow as shown and confirm that the stand is locked. Open the stand with widely extended until feeling a "click" feeling.
To reattach the stand, please refer to monitor's user's manual.

Before using:
Use this stand with widely extended until feeling a "click" feeling.
CAUTION: Improper setting may cause the monitor fall down and make serious damage to the monitor.
Human Sensor position is below as normal stand. Please make sure there is no object in front of Human Sensor.
Be sure to observe the cautions described in the monitor's operating manual when handling the monitor.

Español

⚠️ **Advertencia**

Los elementos marcados con este símbolo contienen instrucciones que, de ser ignoradas o seguidas inadecuadamente, podrían ocasionar daños físicos e incluso la muerte.

⚠️ **Precaución**

Los elementos marcados con este símbolo contienen instrucciones que, de ser ignoradas o seguidas inadecuadamente, podrían ocasionar daños físicos o daños a la propiedad.

⚠️ **Advertencia**

⚠️

• Al instalar el monitor MultiSync, asegúrese de haberlo instalado correctamente según las instrucciones. Una instalación inadecuada podría provocar que el monitor MultiSync basculara y como resultado ocasionara daños físicos.

❗

• Asegúrese de seguir estrictamente el conjunto de las instrucciones así como de fijar cada uno de los tornillos en los lugares destinados a tal efecto. Si no sigue estas instrucciones puede provocar que el monitor MultiSync bascule, caiga, se rompa o que ocasione accidentes imprevistos después de su instalación.

🚫

• Nunca altere los componentes proporcionados. Al hacerlo, podría provocar que el monitor MultiSync basculara y produjera daños físicos.

🚫

• Nunca utilice partes o componentes dañados. Al hacerlo, podría provocar que el monitor MultiSync basculara y produjera daños físicos. Si encuentra partes o componentes dañados póngase en contacto con el distribuidor al por menor al que compró el producto para solicitar asistencia.

🚫

• Nunca desplace el soporte y el monitor MultiSync sujetando sólo el soporte mientras ambos estén acoplados. Al hacerlo, podría provocar que el monitor MultiSync basculara y produjera daños físicos.

⚠️ **Precaución**

⚠️

• Al acoplar el monitor MultiSync al soporte, asegúrese de sujetar bien el monitor MultiSync. No hacerlo podría provocar que el monitor basculara y que ocasionara daños físicos.

⚠️

• Apague el monitor MultiSync durante la fijación al soporte y desenchufe cualquier dispositivo conectado así como el cable de alimentación antes de proceder.

Installing stand:
You use this stand for both size 20" (EX201W) and 23" (EX231W/EX231Wp) by change attachment foot.
CAUTION: Do not use this stand for EX201W with attachment foot for EX231W/EX231Wp. It may cause monitor fall down and make serious damage to the monitor.

For EX201W user: Proceed to step ❸.

For EX231W or EX231Wp user: Change attachment foot following the below instruction.

❶ Press Quick Release Button **A** and pull out the attachment foot.

❷ Attach the attachment foot with "23 only".

❸ 1) Turn off the power to the monitor.
2) Paste two rubber feet **B** on the bottom of the monitor.
3) Place monitor face down on a non-abrasive surface.
NOTE: Handle with care when placing monitor face down to avoid damaging the front control keys.Put the upper hooks of the stand in the slot of the monitor then push stand into monitor in direction of the arrow as shown and confirm that the stand is locked. Open the stand with widely extended until feeling a "click" feeling.
To reattach the stand, please refer to monitor's user's manual.

Before using:
Use this stand with widely extended until feeling a "click" feeling.
CAUTION: Improper setting may cause the monitor fall down and make serious damage to the monitor.
Human Sensor position is below as normal stand. Please make sure there is no object in front of Human Sensor.
Be sure to observe the cautions described in the monitor's operating manual when handling the monitor.

Italiano

⚠️ **Avviso**

Gli articoli contrassegnati da questo simbolo indicano che contengono istruzioni che se ignorate o non seguite scrupolosamente, potrebbero causare decessi o lesioni.

⚠️ **Attenzione**

Gli articoli contrassegnati da questo simbolo indicano che contengono istruzioni che se ignorate o non seguite scrupolosamente, potrebbero causare lesioni o danni alla proprietà.

⚠️ **Avviso**

⚠️

• Quando si installa il monitor MultiSync, accertarsi di averlo installato correttamente secondo le istruzioni. Un'installazione scorretta potrebbe causare ribaltamenti del monitor MultiSync, e ciò potrebbe causare a sua volta lesioni.

❗

• Accertarsi di seguire le istruzioni di assemblaggio nell'ordine dato e di avvitare fermamente le viti nella posizione corretta. Nel caso in cui, dopo l'installazione del MultiSync monitor, tali istruzioni non vengano seguite, il monitor potrebbe ribaltarsi, cadere, danneggiarsi, o causare altri tipi di incidenti non sperimentati.

🚫

• Non alterare mai nessuno dei componenti, poiché ciò potrebbe causare un ribaltamento del monitor MultiSync, cosa che potrebbe causare lesioni.

🚫

• Non usare mai nessuna delle parti danneggiate poiché ciò potrebbe causare un ribaltamento del monitor MultiSync, cosa che potrebbe causare lesioni. Se trovi le parti o i componenti danneggiati, contatta il rivenditore da cui hai acquistato il prodotto per assistenza.

🚫

• Quando sposti il supporto e il monitor MultiSync mentre sono ancora collegati, non muovere mai il monitor e lo stand da solo, così facendo potresti far cadere il monitor MultiSync, cosa che potrebbe causare lesioni.

⚠️ **Attenzione**

⚠️

• Quando si collega un monitor MultiSync al supporto, accertarsi di tenere il monitor MultiSync vicino altrimenti il monitor potrebbe cadere, cosa che potrebbe causare lesioni.

⚠️

• Quando si collega il monitor MultiSync, prima di iniziare, spegnere il monitor e i dispositivi collegati quindi rimuovere il cavo dalla presa prima.

Installing stand:
You use this stand for both size 20" (EX201W) and 23" (EX231W/EX231Wp) by change attachment foot.
CAUTION: Do not use this stand for EX201W with attachment foot for EX231W/EX231Wp. It may cause monitor fall down and make serious damage to the monitor.

For EX201W user: Proceed to step ❸.

For EX231W or EX231Wp user: Change attachment foot following the below instruction.

❶ Press Quick Release Button **A** and pull out the attachment foot.

❷ Attach the attachment foot with "23 only".

❸ 1) Turn off the power to the monitor.
2) Paste two rubber feet **B** on the bottom of the monitor.
3) Place monitor face down on a non-abrasive surface.
NOTE: Handle with care when placing monitor face down to avoid damaging the front control keys.Put the upper hooks of the stand in the slot of the monitor then push stand into monitor in direction of the arrow as shown and confirm that the stand is locked. Open the stand with widely extended until feeling a "click" feeling.
To reattach the stand, please refer to monitor's user's manual.

Before using:
Use this stand with widely extended until feeling a "click" feeling.
CAUTION: Improper setting may cause the monitor fall down and make serious damage to the monitor.
Human Sensor position is below as normal stand. Please make sure there is no object in front of Human Sensor.
Be sure to observe the cautions described in the monitor's operating manual when handling the monitor.

日本語

安全上のご注意

この取扱説明書に使用している表示と意味は次のようになっています。

⚠️ **警告**

この表示を無視して、誤った取り扱いをすると、人が死亡または重傷を負う可能性が想定される内容を示しています。

⚠️ **注意**

この表示を無視して、誤った取り扱いをすると、人が傷を負う可能性が想定されるか、物的損害の発生が想定される内容を示しています。

図記号の意味は次のとおりです。

⚠️ 注意してください。

🚫 絶対におこなわないでください。

❗ 必ず指示に従いおこなってください。

⚠️ **警告**

⚠️

・液晶ディスプレイを設置する際は、本書に基づいて正しく取り付けてください。誤った設置は液晶ディスプレイが転倒してけがの原因となります。

❗

・組み立ての手順を守り、指定の箇所はすべて確実にネジ留めてください。指定を守らないと液晶ディスプレイの取り付け後に、破損や転倒、落下などの思わぬ事故の原因となることがあります。

🚫

・部品を改造しないでください。液晶ディスプレイが転倒してけがの原因となります。

⚠️ **注意**

⚠️

・壊れた部品を使用しないでください。液晶ディスプレイが転倒してけがの原因となります。万一、部品が壊れた場合は販売店にご相談ください。

🚫

・本スタンドは指定の液晶ディスプレイ以外に取り付けしないでください。転倒してけがの原因となります。

🚫

・本スタンドを液晶ディスプレイに取り付けた状態で移動する際は、スタンド本体を持たないでください。液晶ディスプレイが転倒してけがの原因となります。

For EX201W

474.8

279

132.1

Weight: ??

For EX231W / EX231Wp

539.7

316.4

141.4

Weight: ??

スタンドの取り付け方法:
このスタンドは、アタッチメントフットを付け替えることにより、20インチの液晶ディスプレイ(EX201W) にも 23インチの液晶ディスプレイ(EX231W / EX231Wp) にも使用することができます。

⚠️ 注意 20インチの液晶ディスプレイ (EX201W) に23インチの液晶ディスプレイ (EX231W / EX231Wp) 用のアタッチメントフットをつけた状態で使用しないでください。液晶ディスプレイが倒れて、故障やけがの原因となる場合があります。

EX201Wでお使いの場合：手順3に進んでください

EX231WまたはEX231Wpでお使いの場合：下記手順1、手順2でアタッチメントフットを付け替えてください。

手順1: 固定用ボタン(A)を押したまま、アタッチメントフットを取り外す。(❶)

手順2: 「23 only」と記載されたアタッチメントフットを取り付ける。(❷)

手順3: 1) 液晶ディスプレイの電源を切る。

2) 平らで安定した場所に柔らかい布を敷き、表示画面を下向きにして置く。

お願い 表示画面を下向きにして置く時は、前面部に強い力をかけないでください。故障の原因になる恐れがあります。

ゴム足(B)×2をそれぞれ液晶ディスプレイの下側の両端に取り付ける。

3) スタンドのツメ(3箇所)を本機背面側の差込口に差し込んで、❸ のように取り付ける。

クリック感があるまで、スタンドをいっぱいに広げる。

スタンドをはずす場合は、液晶ディスプレイの取扱説明書を参照して同様な方法でおこなってください。

ご使用の前に:
このスタンドは、クリック感があるまでいっぱいに開いた状態でお使いください。

⚠️ 注意 正常な使用方法で使わないと、液晶ディスプレイが倒れて故障の原因となる場合があります。

ST-EX2023を取り付けた場合、人感センサーの位置が通常の場合よりも低くなります。人感センサーの前に障害物がないようにしてください。

その他の注意はディスプレイの取扱説明書を参照してください。

简体中文

安全注意事项（本说明书所用符号说明）

安装前，请务必仔细阅读如下说明。

⚠️ **警告**

带有此符号标记的项目表示该项目包含重要指示，如果忽视或不正确遵守这些指示，则可能导致死亡或人身伤害。

⚠️ **注意**

带有此符号标记的项目表示该项目包含重要指示，如果忽视或不正确遵守这些指示，则可能导致人身伤害或财产损失。

⚠️ **警告**

⚠️

• 安装MultiSync显示器时，请务必按照本说明书中的说明正确进行安装。安装不当可能导致MultiSync显示器翻倒，从而导致人身伤害。

❗

• 请务必按照安装说明书所述的顺序，将所有螺丝牢固地拧入指定的位置。不按照说明书操作，可能导致MultiSync显示器在安装好后翻倒、掉落、损坏或导致其他意外事故。

🚫

• 切勿替换任何附带的组件，否则可能导致MultiSync显示器翻倒，从而导致人身伤害。

🚫

• 切勿使用任何损坏的零件或组件，否则可能导致MultiSync显示器翻倒，从而导致人身伤害。如果发现任何零件或组件损坏，请联系购买该产品的零售店请求协助。

🚫

• 当保持底座和MultiSync显示器固定在一起进行移动时，切勿仅抓住底座来移动底座和显示器，否则可能导致MultiSync显示器翻倒，从而导致人身伤害。

⚠️ **注意**

⚠️

• 将MultiSync显示器安装在底座上，请务必在安装时将MultiSync显示器固定在某一位置，否则可能导致其翻倒，从而导致人身伤害。

⚠️

• 安装MultiSync显示器时，请先关闭显示器和所有连接设备的电源并将电源线从电源插座上拔出，然后进行安装。

Installing stand:
You use this stand for both size 20" (EX201W) and 23" (EX231W/EX231Wp) by change attachment foot.
CAUTION: Do not use this stand for EX201W with attachment foot for EX231W/EX231Wp. It may cause monitor fall down and make serious damage to the monitor.

For EX201W user: Proceed to step ❸.

For EX231W or EX231Wp user: Change attachment foot following the below instruction.

❶ Press Quick Release Button **A** and pull out the attachment foot.

❷ Attach the attachment foot with "23 only".

❸ 1) Turn off the power to the monitor.
2) Paste two rubber feet **B** on the bottom of the monitor.
3) Place monitor face down on a non-abrasive surface.
NOTE: Handle with care when placing monitor face down to avoid damaging the front control keys.Put the upper hooks of the stand in the slot of the monitor then push stand into monitor in direction of the arrow as shown and confirm that the stand is locked. Open the stand with widely extended until feeling a "click" feeling.
To reattach the stand, please refer to monitor's user's manual.

Before using:
Use this stand with widely extended until feeling a "click" feeling.
CAUTION: Improper setting may cause the monitor fall down and make serious damage to the monitor.
Human Sensor position is below as normal stand. Please make sure there is no object in front of Human Sensor.
Be sure to observe the cautions described in the monitor's operating manual when handling the monitor.